

The ARCA-SWISS p0 instructions







Congratulations on your purchase of the latest Monoball® p0 from ARCA-SWISS. The legendary Monoball® tripod head series with an aspherical ball.

Please note that the knurled ring to lock the Monoball does need some vertical play to function properly !


Your Monoball® p0 needs no maintenance and will serve you for many years.

If the Monoball is not moving as smoothly, clean the ball with a soft cloth and alcohol. However, please make sure that sand and dust do not enter the housing.


DO NOT USE ANY LUBRICANTS, as this would impair proper function.



Open position



Sliding position



Push firmly to lock

ARCA-SWISS International
29 quartier de l'Europe
FR-25048 Besançon

arca-swiss@wanadoo.fr
T: 0033 381 85 40 60
F: 0033 381 85 40 69



The ARCA-SWISS monoball® Fix system



802262 Cameraplate monoball®Fix Leica M2 -> M7

802255 Cameraplate monoball®Fix Sony NEX-5

802260 Cameraplate monoball®Fix 32 universal

041036 Bench 200 monoball®Fix

041035 Bench 150 monoball®Fix

802294 Lensplate 100 monoball®Fix

802265 Cameraplate monoball®Fix 48 universal

802299 Connection angle

802273 Cameraplate monoball®Fix 55 Hasselblad ; Leica M8-M9; Olympus E30

802282 Cameraplate 300 monoball®Fix

052006 Carrier universal.

802270 Cameraplate monoball®Fix SLR index (**) 60

802281 Cameraplate 200 monoball®Fix

802280 Cameraplate 150 monoball®Fix

802283 Cameraplate 100 monoball®Fix

802308 L-Bracket monoball®Fix

802292 Cameraplate monoball®Fix Hasselblad Variokit

802288 Cameraplate monoball®Fix SLR Variokit for Canon 1D-series ; Nikon D3-series

802012 monoball®Fix quickset device 1/4"

802025 monoball®Fix quickset device upgrade for p0

802026 monoball®Fix quickset device upgrade for monoball® Z-series, p1 and Cube

802027 monoball®Fix quickset for Carrier universal and M-two

802013 Quickset base (for mounting Quickset on Cameraplate)

802015 N (*) Quickset device classic with screw to convert a monoball

802002 N (*) Quickset device classic round with 1/4" - 3/8"

802019 N (*) Quickset device flipLock® with screw to convert a monoball®

802010 N (*) Quickset device flipLock® round with 1/4" - 3/8"

802310 monoball®Fix panoramic Quickset device 1/4" - 3/8"

802310.1 monoball®Fix panoramic Double Quickset device

802285 Cameraplate monoball®Fix Mamiya Variokit

802290 Cameraplate monoball®Fix SLR index (**) Variokit

(**) for Canon 5D / 50D ; Nikon D700 / D300 ; Sony A1 pha 850 / 900

(*) Accepts both classic and monoball®Fix cameraplates

Der p0 kann jederzeit mit der neuartigen schnellspannvorrichtung slideFix ausgestattet werden. Der slideFix ermöglicht einen blitzschnellen kamerawechsel und sichert dabei augenblicklich ihre kamera, trotzdem haben Sie die möglichkeit ihre kamera entsprechend der länge der gewählten platte zu verschieben. Beispiele; gewicht ausgleichen oder die für panoramaaufnahmen notwendige verschiebung des objektives, um den nodalpunkt in den drehpunkt des stativekopfes zu bringen.